



A DIVISION OF PJML INDUSTRIES, INC.

Staple or Nail Down Installation

Wood Subfloor

- Minimum of $\frac{3}{4}$ " thick of exterior plywood subfloor over 16" o.c. floor joist.
- Subfloor must be flat and structurally sounded.
- All crawl space must be dry and well ventilated.
- All foreign materials shall be removed for the subfloor surface and swept clean.

Installation instructions

- Use 15lb asphalt saturated felt paper to cover clean subfloor wall to wall with lap edges of 4".
- Flooring should be lay at right angles to the floor joist and if possible, in the direction of the longest dimension of the room.
- Begin laying T & G plank from left to right, install planks so that the tongue faces out. Leave a minimum of $\frac{3}{8}$ " space between the floor board to the adjacent wall for expansion.
- All end joints of plank should be staggered to achieve the best appearance.
- Nailing schedule should be 8" centers at the tongue and nail within 2" of each end joints.
- Use minimum $1\frac{1}{2}$ " staple and $\frac{1}{4}$ " crown or $1\frac{1}{2}$ " power cleats.
- Do not install any plank with visible and obvious defects.
- Maintain room temperature between 60 to 65 degree and humidity level at 50 to 55 degree during installation

